

# Bedienungsanleitung

## 17001

Soundsystemadapter mit vier manuell einstellbaren Ausgängen zum Anschluss eines original verbauten Soundsystem an ein Iso Nachrüstradios.

Bei Fahrzeugen bei denen kein OEM-ISO Stecker verbaut ist muss unter Umständen ein Adapterkabel verwendet werden. Zum Beispiel ein LFB-Adapter der 67XXX Serie oder ein normales Fahrzeugspezifisches ISO-Kabel.

Das Interface ermöglicht es Ihnen die zwei Front- und zwei Hecklautsprecher jeweils einzeln über einen frei einstellbaren Widerstandswert auf Ihr neues System zu justieren.

Beachten Sie das die Remoteverbindung zum Einschalten des Verstärkers von Ihrem Radio über das Interface geleitet wird. Nutzen Sie dazu die vorhandenen blauen Kabel mit losen Enden.



### Kompatibilitätsliste

- Landrover - Discovery II (1998 - 2004)
- Mazda - MX-5 (NC) (2005 > )
- Mazda - RX-8 (2003 - 2010)
- Mercedes - C-Class (W202) (1993 - 2000)
- Mercedes - E-Class (W210) (1995 - 2002)
- Nissan - 350Z Coupe, Roadster (2003 - 2010)
- Nissan - Murano I (2005 - 2008 )
- Nissan - Murano II (2008 > )
- Nissan - Skyline R34 (1999 - 2002 )
- Nissan - Skyline R35 (2009 > )
- Saab - 9-3 (2007 - 2012 )
- Saab - 9-5 (2006 - 2010)

# Installation and operating Manual

## 17001

Audio interface with 4 channel adjustable line out put for connecting cars with OEM amplifiers to the ISO connectors of an after-market car radio.

Use with car specific iso leads for Nissan Bose, Mazda Bose, Honda Premium sound. Saab Bose or any cars with OEM low level pre-amplifier signals from the original radio

This lead has 8 way ISO connectors at both ends so if it is used on a car with different connectors (such as SAAB or Mazda) then you need to use the car specific lead as well. This might be a steering control or a standard iso audio cable.

Active speakers 4 channel adjustable.

Always ensure that you connect the remote turn on wire from the new aftermarket radio to the Blue / white wire on this interface



### Compatibility list

- Landrover - Discovery II (1998 - 2004)
- Mazda - MX-5 (NC) (2005 > )
- Mazda - RX-8 (2003 - 2010)
- Mercedes - C-Class (W202) (1993 - 2000)
- Mercedes - E-Class (W210) (1995 - 2002)
- Nissan - 350Z Coupe,Roadster (2003 - 2010)
- Nissan - Murano I (2005 - 2008 )
- Nissan - Murano II (2008 > )
- Nissan - Skyline R34 (1999 - 2002 )
- Nissan - Skyline R35 (2009 > )
- Saab - 9-3 (2007 - 2012 )
- Saab - 9-5 (2006 - 2010)